SKAA® RECEIVER USER'S GUIDE

Each SKAA receiver uses a *Green List* to remember your *favourite* audio sources (SKAA transmitters). A Green glowing Indicator on your receiver means you are listening to a favourite, or hunting for one. You can also *explore* to find new transmitters—an Amber Indicator means you are *exploring* for transmitters which are not on your Green List. The I Bond Button on your receiver lets you select which audio source (SKAA transmitter) you're listening to.

Essentials

| | Command | Indicator |
|-----------------------|---|---|
| Hold a few seconds | Add / Delete Manually add / delete the current transmitter to / from your Green List | to = Added (flash) = Deleted |
| - | Auto Add SKAA will automatically add the current Amber transmitter to your Green List if you listen to it for 30 minutes | to = Added |
| 1 Click | <u>Green Mode</u> Rotate through your list of favourite transmitters (Green List) — when a favourite transmitter is found, the search stops and audio plays from that transmitter | <pre>(dim) = Hunting (flash) = Next one (bright) = Bonded</pre> |
| 2 Clicks | Amber Mode Explore for new, unknown transmitters (ones which are not already on your Green List) | (dim) = Hunting (bright) = Bonded |

More Commands

| □ Button | Command | Indicator |
|-------------------------|---|---|
| 3 Clicks | Mute do again to Unmute; any Click command will first Unmute and then do its function | O, Or O = Muted (slow flash) |
| 4 Clicks | Red Mode If you have 2 or more transmitters on your Green List, power on just the one you want to hear and it plays automatically. | (dim) = Hunting (bright) = Bonded |
| 6 Clicks | Factory Reset Clear Green List. Start Over! | (flash) = Reset Done |
| Hold during power on | Make a Cluster of Receivers: 1. Power off all transmitters and receivers 2. Power on the Master receiver while holding down its Bond Button—hold the button down until the Indicator begins to flash Red 3. With the remaining receivers within 3 meters of the Master receiver, power on the first one, wait for its Indicator to flash Red and then power on the second one; continue until all of them are powered on 4. Once all of the Indicators stop flashing (turn solid Red), power off all of the receivers | (flash) = Receiver has entered 'Cluster Up' mode (bright) = The Cluster has been successfully made |

QUESTIONS AND ANSWERS

| Question | Answer | |
|--|--|--|
| How does the Green List work? | You can store up to 10 SKAA transmitters on your Green List. These are your "favourite" audio sources. Every time you add a transmitter, it is assigned the first open spot on the Green List. When you single click the bond Button, the receiver hunts through the Green List much like a car radio hunts for radio stations when you press seek. If the Indicator is dim Green and flashes every few seconds, this tells you the receiver is hunting through the Green List. Say you have 5 transmitters on your Green List; your receiver will hunt through the list one by one: 1, 2, 3, 4, 5 and then back to 1 and so on. The dim Green Indicator flashes every time the receiver moves to the next spot on the list. This hunting goes on for up to 1 minute. If your receiver doesn't find any of your favourite transmitters, it stops hunting and just waits for the last bonded favourite. If your receiver does find one of your favourite transmitters, the hunting stops, the Indicator turns bright green, and your receiver starts playing audio from that favourite. A dim Green Indicator that is NOT flashing means the receiver is just sitting on one spot, waiting for a specific favourite transmitter to show up. | |
| How do I bond with a specific Green transmitter? | Play audio from your source device and ensure it has a SKAA transmitter connected. Click the Sound Button on your receiver. The receiver hunts through the Green List, flashing the Indicator as it goes. Once your receiver finds one of your favourite transmitters, it bonds to it and plays audio from that transmitter. If that isn't the transmitter you wanted, click the Bond Button once more. Repeat until your receiver bonds with the transmitter you want and you're hearing the correct audio playing. | |
| How do I select transmitters if I can't reach my Bond Button? | Say you want to put your receiver on a high shelf where you can't reach the Bond Button easily. First, set up your Green List: add all of the transmitters you'll want to use. Then 4-click the Bond Button to enter Red Mode. Now put the receiver up on the high shelf. Power on just one of your transmitters and power off all others. The receiver automatically bonds to the transmitter that's on. | |
| How do I delete a transmitter from my Green List? | Factory Reset (6 Clicks of the Bond Button) clears the Green List and lets you start over from scratch. If however, you'd like to delete just one transmitter from your Green List, first bond your receiver to the transmitter you wish to delete. See the section above: How do I bond with a specific Green transmitter? Once you are bonded to it, hold down the Dond Button for a few seconds until you see the Indicator flash Red –this Red flash means the transmitter has been deleted. | |
| What is a Cluster? | Clusters are an optional convenience for "power users". A Cluster is several SKAA receivers behaving as one product. A left & right speaker pair, for example, or a sound bar and subwoofer. | |
| What is the Master receiver? | In any Cluster, there is a single Master receiver, and all of the other receivers in the Cluster follow its behaviour. You can control the entire Cluster by operating the The Bond Button of the Master. A receiver must have a physical Bond Button in order to become the Master. | |
| How do I "uncluster" several receivers? | Do the Make a Cluster of Receivers procedure once for each receiver, but omit Step 3. Do them one at a time. This gives each of the receivers a functioning The Bond Button, and each of them will thereafter operate independently. | |
| What are some tips for making Clusters? | Each step in the Make a Cluster of Receivers procedure has a 10-second time limit. When you see the Master's Indicator start to flash Red, you have 10 seconds to power on the next receiver. When that receiver's Indicator starts to flash Red, you have 10 more seconds to power on the next one, and so on. | |
| Why does only one of my Bond Buttons work? | When you make a Cluster from several receivers, the first one powered on in the Make a Cluster of Receivers procedure becomes the Master of the Cluster. Only the Master's Dend Button works because a Cluster uses just one Green List –the Master's Green List. The Bond Button of each of the other receivers will work only for the Mute / Unmute function (3-Click of the Bond Button). | |
| Can any group of receivers be made into a Cluster? | No. The receivers must be members of the same product family. If they are not, the Make a Cluster of Receivers procedure won't work. This is because only receivers which were designed to work together (as a single product) can be made into a Cluster. | |